

BIS CRS 印度

產品類別

- **Standard : IS 16046(Part 1):2018 / IS 16046(Part 2):2018**
Sealed Secondary Cells / Batteries Containing Alkaline or Other Non-Acid Electrolytes for Use In Portable Application (二次電池與電芯)
- **Standard : IS 13252(Part 1):2010+A1:2013+A2:2015**
 1. AC Adapter for IT Equipment / Switching Power Supply
 2. Automatic Data Processing Machine (Server, Storage, Panel PC)
 3. Laptop / Notebook / Tablet
 4. Plasma / LCD / LED Television
 5. Printers
 6. Plotters
 7. Scanners
 8. Set Top Box (資訊類產品)
- **Standard : IS 616:2017**
Power Adapter for Audio, Video & Similar Electronic Apparatus (視聽類產品)

申請流程

開案階段：
向認可實驗室提出 Test Request

測試階段：
1. 寄送樣品至認可實驗室測試
2. 出草稿報告
3. 出正式報告

投件階段：
1. 線上投件
2. 紙本投件(申請文件 + 測試報告)
3. 審核期間 Query 產生與解決

發證 (R 碼)：
1. 審核時間
Fresh 案件：10-12 周
Inclusion 案件：8-10 周
2. 證書兩年效期

認證 Logo

發證之後需要標上 BIS LOGO, R 碼, IEC+印度標準

IS 16046 (Part 1):2018 / IEC 62133-1:2017 IS 16046 (Part 2):2018 / IEC 62133-2:2017 IS 13252 (Part 1) / IEC 60950-1



R-XXXXXXXX
www.bis.gov.in



R-XXXXXXXX
www.bis.gov.in



R-XXXXXXXX
www.bis.gov.in

技術文件

Battery	Adapter
<ol style="list-style-type: none"> 1. Pack + Cell Spec 2. Cell BIS Cert + Report 3. Label 4. Barcode Rule 5. Layout 6. Schematic 7. Packaging 8. Barcode Rule 9. CDF (Critical component list) 10. ISO Cert. 11. UN38.3 Test Report 	<ol style="list-style-type: none"> 1. Label 2. Layout 3. Schematic 4. User Manual or Product Spec

Label 要求

Battery	Adapter
<ol style="list-style-type: none"> 1. Product Name 2. Model 3. Rating (Nominal Voltage + Rated Capacity) 4. Trademark 5. IEC Designation 6. Polarity 7. Manufacturer 8. Country of Origin 9. Manufacture Date 	<ol style="list-style-type: none"> 1. Product Name 2. Model 3. Rating 4. Trademark or Manufacturer 5. Country of Origin

ATC 特色

- 印度當地分公司，有效及快速處理投件與後續審件問題
- 長期與多個當地實驗室配合，測試問題解決快速
- 案件經驗豐富，與認證單位關係良好